

HD DVD player HD-E1 Firmware Version 2.5

Thank you for your updating your HD DVD player firmware.
Improvements have been added.

Output range selection

To select the RGB range according to the output range of the connected DVI monitor.


From SETUP MENU, select "Picture" > "RGB Output Range", then press OK.

Standard : For a monitor of RGB range 16-235.

Enhanced : For a monitor of RGB range 0-255.

Note

- If "Standard" pales black or "Enhanced" blackens too much, change the setting.



GMT time zone selection

You need to reset the player's clock, as parameters of "Time Zone" have changed.

On the menu of "Clock Set", select "Time Zone" then press OK. Select your GMT by ▲/▼, then press OK.

12-language on screen display

Your player can display messages and menus in 12 languages.

English / French / Japanese / German / Spanish / Italian / Dutch / Russian / Swedish / Finnish / Greek / Turkish

Deleted options

